

LES MILLS
SMARTSTEP™


INSTRUCTIONS FOR USE

ASSEMBLY

SMARTSTEP™ equipment comprises of five components:

1x Deck 4x Risers

The deck can be used with or without risers depending on the height required. To attach risers, place either one or two risers under the deck at each end and apply weight to the deck. When the deck and risers are correctly engaged, risers will form a temporary bond with the deck.



To remove the risers from the deck, gently pull the risers and deck apart

INSTRUCTIONS FOR USE, STORAGE AND CARE

Please see our guidelines for use and care of the SMARTSTEP™ at www.lesmills.com/merchandise/equipment/care.

Do not drop, throw or knock the SMARTSTEP™ deck or risers. Do not drop weights on top of the SMARTSTEP™ deck or risers. This will help to avoid damage to the item finish or the item itself.

Store the SMARTSTEP™ equipment by stacking the decks on top of one another, and the risers on top of one another on a solid, level surface. Maximum recommended stack height of 21 Decks or 32 risers.

DO NOT STORE the SMARTSTEP™ equipment in extreme temperatures (<-5 degrees Celcius ; >50 degrees Celcius). Keep product stored away from moisture or direct heat.

Regularly clean the SMARTSTEP™ equipment by wiping down with a damp soft cloth using mild detergent (if necessary).

Do not use the SMARTSTEP™ equipment outside or on non-standard gym/studio flooring.

The SMARTSTEP™ was designed to withstand weights of up to 136kg/300lbs.

When using or handling your SMARTSTEP™ equipment, do not bring it into contact with sharp or abrasive objects/materials.

HORIZONTAL USE

A maximum of 6 risers may be used under the SMARTSTEP™ deck at each end. Follow the assembly instructions when attaching risers.

INCLINE USE

For all incline uses, one end of the deck must be resting on the ground as shown.

To use the SMARTSTEP™ on an incline, position one end of the deck on the ground, and the other correctly on the riser(s) by placing the recess of the on the rim of the top riser as shown. Supine and prone bench incline work (lying on deck)

Up to four risers may be stacked under one end of the deck to achieve a range of incline angles.

PROPULSIVE WORK (SPRINGING OFF DECK)

The user is recommended to limit incline to one riser high (a single riser under one side of the deck) for propulsive work. Using more than one riser for propulsive work may lead to injury and is therefore not recommended.

SMARTSTEP™ EQUIPMENT – WARRANTY INFORMATION

WARRANTY INFORMATION

At Les Mills Merchandise Limited (Les Mills) we stand behind our materials and manufacturing and offer customers who purchase SMARTSTEP™ equipment for commercial or in-club use a two year warranty on all SMARTSTEP™ Equipment for manufacturing faults caused by materials or labour that occur during the warranty period. Les Mills' local SMARTSTEP™ distributor will, at its discretion, either repair or replace faulty SMARTSTEP™ equipment in accordance with the conditions set out below.

PERSONAL USE CUSTOMERS ONLY

As a consumer, you are entitled to the applicable legal rights stated in your national legislation concerning the commerce of consumer goods. This warranty does not restrict these rights.

WARRANTY TERMS

This warranty is valid only in countries where Les Mills has an authorised SMARTSTEP™ equipment distributor. It covers manufacturing faults occurring during the warranty period in SMARTSTEP™ equipment purchased from Les Mills or a distributor authorised by Les Mills. The warranty applies only to the original purchaser and does not cover second hand equipment or re-sold equipment. The equipment must remain in the possession of the original buyer/owner and bear the original manufacturer's serial number. The two year warranty period commences from the date on which the original buyer purchases the equipment. Warranty repairs will not extend the warranty period.

You can find the serial number for your SMARTSTEP™ equipment underneath the deck on a white sticker.

EXCLUSIONS

This warranty covers only failures due to manufacturing faults that occur during normal use. This warranty does not extend to faults resulting from normal wear, misuse, abuse, corrosion, damage incurred during loading or transportation, where the SMARTSTEP™ equipment has been used other than as recommended by Les Mills (See the instructions below and our guidelines for using the SMARTSTEP™ equipment at www.lesmills.com/merchandise/equipment/care) or modified without the consent of Les Mills or improper storage. This warranty is invalid where the SMARTSTEP™ equipment does not bear its original manufacturer's serial number. The warranty is invalid where the SMARTSTEP™ equipment that is the subject of the warranty claim has been disposed of prior to a warranty claim being closed by Les Mills.

Neither Les Mills nor its authorised local SMARTSTEP™ distributor will be liable for any defects due to reasons beyond their control or for consequential damages or for breach of any implied warranty on the range of SMARTSTEP™ equipment.

CLAIM PROCESS

For enquiries, or to make a warranty claim, either contact your local Les Mills authorised SMARTSTEP™ equipment distributor, visit our website www.lesmills.com/merchandise/equipment/warranty/OR email Les Mills at warranty@lesmills.com. Please keep your invoice as proof of purchase as you will need it to submit a warranty claim.

You will also need to include the following details about the faulty SMARTSTEP™ equipment: (i) the serial number, (ii) the date of delivery, (iii) information about the place and conditions of use of the faulty SMARTSTEP™ equipment and a precise description of the fault (including photographs). The Les Mills local SMARTSTEP™ equipment will liaise with Les Mills to assess the issue and determine if the warranty applies. We will then work with our local SMARTSTEP™ equipment to repair or replace the SMARTSTEP™ equipment. If we ask you to return the faulty SMARTSTEP™ equipment, we will cover the cost of doing so.